



Crack Filler – ACF-1 Directions for Use

Just clean crack, shake, snip open and squeeze into crack.

ACF-1 is a specially formulated latex rubber polymer blend that provides extended life and greater durability than ordinary cold pour formula crack fillers. It can be used in asphalt cracks up to 9 mm wide.

ACF-1 is fortified with latex and asphalt binders to strengthen the bond and has a low VOC formula.

Application:

- 1) Remove all dirt, grass, old crack filler and debris from crack to be filled.
- 2) Shake bottle well before using. ACF-1 is Pre-mixed. DO NOT DILUTE.
- 3) For deep/large cracks we recommend using DP-1 Crack Filler. Or fill larger cracks with sand or backer rod to within 6mm of the surface before applying ACF-1 Crack Filler.
- 4) ACF-1 Crack Filler will dry to the touch within 30 minutes and, depending on outdoor conditions, should be fully dry within 24-48 hours.

Caution: Do not allow product to freeze. Apply when temperature is at least 12 degrees Celsius and rising. Do not apply if rain is forecast for 24 hours or crack is larger than 9mm.

Clean Up: Uncured crack filler will clean up with soap and water; cured crack filler will clean up with turpentine.

Ph: 1300 789 967 **International:** +61 7 3061 6662 **Fax:** +61 7 3206 8339 **Issued** 14/5/14

